

MOLDA FAIBLE EXPANSION

Ceramics

PRODUCT DESCRIPTION

Molda Faible Expansion is a formulated plaster used in ceramics for modelling and to produce working moulds for tableware and figurines when high strength and low expansion are required. Molda Faible Expansion can also be used to make case moulds. It is also used in Art & Decoration and construction material formulations.

PRODUCT BENEFITS

- + Designed to reduce expansion
- + High strength
- + Balance between mechanical properties and absorption capability

APPLICATIONS

Artistic, Tableware

TECHNICAL INFORMATION

Plaster to Water Ratio	
Plaster to Water Ratio (by weight)	2.20:1
Water to plaster ratio (by weight)	45%
Plaster to water mix ratio (by weight)	100/45
Chemical Properties	
Chemical Name	Calcium sulphate hemihydrate
Chemical Composition	CaSO ₄ .1/2H ₂ O
Minimum gypsum purity %	95
Colour	White
Setting Parameters	
Vicat Ring Fluidity (cm)	18
Initial setting time (minutes)	9
Linear Expansion (%)	≤ 0.10
Mechanical Properties	
Flexural Strength (MPa)	10
Brinell Hardness (MPa)	80
Dry compressive strength (Mpa)	26
Physical Properties	
Particle Size (% weight retained)	≤ 2.00 % at 100 µm
Loose bulk density (kg/m ³)	875

The technical data outlined represents typical figures only. For further details, please contact Saint-Gobain Formula directly.

INSTRUCTIONS FOR USE

The recommended plaster to water ratio is between 1.90:1 and 2.20:1, with a mixing time of approx. 2 to 4 minutes. The precise consistency to use will need to be adjusted to suit the individual application. Changes to plaster to water ratio will influence product performance particularly setting time and strength.

PACKAGING AND SHELF LIFE

	Packaging Available	Shelf Life (Month)
Bag	25 kg	10

When stored under dry conditions and in its original packaging, the product will have a specified shelf life that commences from the date of manufacture that is displayed on each sack. Shelf life depends on the packaging type. For those products where a defined 'best before' date is applicable, BBE (Best Before End) followed by the date will be displayed on each sack.

STORAGE

Plaster based products are not recommended for conditions where they are likely to be located externally or in any way subjected to weathering or excessive dampness.

Absorption of moisture can result in changes to physical properties, including a reduction in the set strength of plasters and also a lengthening of setting time.

Gypsum minerals can be affected by absorption of moisture and may change physical properties.

To help protect the product during use, open or part used bags should be carefully folded and closed. Each bag is date stamped and stocks should be rotated so that the oldest material is used first.

CERTIFICATION



DoP n°CS002

ENVIRONMENT, HEALTH AND SAFETY

Material Safety Data Sheets of Saint-Gobain Formula plasters and gypsum minerals are available for all products and may be obtained directly on our website in the [product](#) and [documentation](#) sections. No liability is accepted by Saint-Gobain Formula for injury to any person or loss or damage to property by improper use of the product.

NOTIFICATION

The plaster to water ratios quoted are those used in Saint-Gobain Formula's standard test methods and are not necessarily those used in practice. The precise consistency to use will need to be adjusted to suit the individual application. Changes to plaster to water ratio will influence product performance, particularly setting time and strength. Unless otherwise stated, Saint-Gobain Formula's standard test methods apply. To obtain a copy of the test method, please contact Saint-Gobain Formula directly. This literature cancels and replaces any previous document. All information given is provided in good faith and may be subject to change. It's advisable to contact Saint-Gobain Formula in case of any doubt arising from the content of such information.

CONTACT

*For any information, please visit our website
www.saintgobainformula.com*



*Sales
contact*



Documentation



*Technical
information*



*Global
information*